

Instruction Manual Aqua Torch Light Up Fountain Indoor and Outdoor Use

Included

One (1) Aqua Torch Light Up Fountain with LED lights.

Technical Data

Power Requirements: 6V DC 1.5 watt Batteries: 4"C" Batteries

Safety Precautions

Caution! Before using for the first time, please read this instruction manual carefully. This manual contains important information, safequards and operating instructions.

- Remove batteries before storing.
- For optimum results, it is highly recommended to use distilled water in the Aqua Torch Fountain.
- Do not place or use foreign articles in Aqua Torch Fountain.
- Do not drop unit.
- Store in cool, dry location when not operating.
- Do not use near tub or shower.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be performed by children without supervision.

Battery Information and Disposal:

- Do not dispose of batteries in a fire.
- For best results, do not mix old and new batteries; do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries).
- For best results, use alkaline batteries.
- Install only new batteries of the same type in your product.
- Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
- If this device is not being used for a long period of time remove batteries and place in a cool dry location.
- Improper handling/disposal of batteries may cause batteries to explode or leak.
- Batteries should be recycled or disposed of as per country, state and local guidelines.

Warning

- This product is a fountain that contains water that can splash. Do not place product on surfaces or fine furniture that can be damaged by water. Place product on a decorator plate or other water-resistant material if concerned with water damage.
- Do not allow pump to run dry, damage may occur.
- Do not allow product outside when temp falls below freezing.
- Do not allow water to freeze in product, damage may occur.

To Use

- 1. Battery box is located at the base. Unscrewing (2 screws) and insert 4 "C" batteries (not included). Follow diagram in battery box for proper orientation. (Do not mix old and new batteries; do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries). Close battery box cover by putting (2 screws) back in place.
- 2. Lift the top lid and pour water in the vessel. For optimum results, use distilled water. The fountain holds a minimum of 10 oz of water and a maximum amount of water is 18 oz.

The more water used, the softer or quieter the sound of the water will be. (Less water will create a louder water sound.)

3. Set power switch, located on the base, to desired modes.

• **ON** – Lights and pump are on constantly. Water will flow.

• **OFF** – Lights and pump are off, no water will flow.

• 4hr – The lights and pump will stay on and water will flow for 4 hours. It will not start again unless you press the 4HR switch on.

4. Place in desired location.

Troubleshooting

- If your Aqua Torch Fountain stops working, please follow the cleaning instructions and run vinegar though it to clean the pump. Also check the batteries, as the pump may not be broken, but the batteries may have run out.
- LED lights are not replaceable.

Care Instructions

- Check water level periodically. Water evaporates over time. It's recommended to change water weekly to help maintain a cleaner product.
- To clean the pump and prevent mineral build up, pour about 8 oz of white distilled vinegar into the inside of the Aqua Torch Fountain and let the pump soak for 15 minutes. Rinse out the vinegar.
- If product becomes dusty or dirty, clean with a dry cloth. Do not use detergent as it may discolor the product.
- If this device is not being used for a long period of time, remove batteries and place in a cool, dry location.

Disposal

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local Authority or retailer for recycling advice.



